

QUIK-SHIELD[®] **108YM, the "Yield Monster",** is an open-cell spray foam with an ultra-low density as low as 0.36lb. It is ideal for high-performance and air barrier insulation applications in residential (IRC) and commercial (IBC) construction. QUIK-SHIELD[®] 108YM is a high yielding product with revolutionary expansion and long-range application features to increase jobsite efficiency.

TYPICAL PHYSICAL PROPERTIES

Properties achieved in a lab environment at 77°F. Field conditions may cause variation in properties.

	PROCEDURE	VALUES
Air Leakage at 3.5 (L/s/m²)	E-283	<0.02
Closed-Cell, content (%)	D-2856	<90
Core Density (nominal, lb/ft³)	D-1622	0.36-0.4
Dimensional Stability (%)	D-2126	<15
Tensile Strength (psi)	D-1623	min 3
RELATIVE INSULATION VALUES (aged)		
R-value at 1"	3.7	
R-value per inch at \geq 3.5"	3.6	
IGNITION BARRIER		
DC 315 (wet mils)	АС377-Арр Х	4
Flame Seal FS 1B (wet mils)	АС377-Арр Х	6
THERMAL BARRIER		
DC 315 (wet mils)	NFPA 286	14
FireShell F10E (wet mils)	NFPA 286	17
No-Burn Thb (wet mils)	UL1715	14
HANDLING PROPERTIES at 77°F (25°C)		

A-SIDE (ISO)B-SIDE (RESIN)Specific Gravity1.231.06Viscosity, cps250±50400±50

RECOMMENDED STORAGE AND SHELF LIFE

• Storage temperatures 50-100°F (10-38°C) See back for preconditioning of material.

6 month shelf life from date of manufacture (unopened containers).

• Keep container tightly sealed.

Store out of direct sunlight, in a cool dry place, avoid freezing.

PRODUCT INFORMATION

Blowing Agent	100% Water Blown	
LEED	QUIK-SHIELD® 108YM has a minimum of 20.1% total renewable/recycle content, 2.2% pre-consumer recycled, 2.9% post-consumer recycled, and 15.0% rapidly renewable.	
Product Color	White to off-white (UV exposure will cause discoloration. Discoloration by itself is not a sign of product damage.)	
Product Packaging	55 Gallon Drum	
Reentry Times	1-hour Reentry for new residential construction with natural ventilation. 12-hour Reentry for commercial/retrofit.	

APPROVALS / COMPLIANCE

QUIK-SHIELD* 108YM has been tested by a third party laboratory (Intertek Testings Services NA, Inc.) and evaluated by Priest and Associates Fire Consultants, LLC. CCRR-1051 Class 1— ASTM E-84

IBC, IRC, IECC: 2009, 2012, 2015, 2018 (AC377)

GREENGUARD Gold Certified

IRC/IBC Section 316.6/2103.9 - Ignition barrier not required in unvented attics.





800-828-1394 | swdurethane.com PUBLISH DATE: 12/2019

PREPARATION OF SUBSTRATES

Providing the proper substrate is the responsibility of the owner, the owner's appointed representative, the contractor, and/or inspector. The following are manufacturer's recommendations. However, other preparation techniques may be required given unique/specialized application circumstances. Contact **SWD Technical Support at 888-380-2022** for additional questions.

It is recommended to remove dust, dirt, oil, paint, and alternative polymers from all surfaces prior to applying SWD products.

See SWD specifications or SPFA guidelines for further details on substrate prep.

See SWB specifications	son ser A guidelines for fulther details on substrate prep.	
Wood	 Ensure wood is relatively dry and protect surfaces from contamination. For moisture content exceeding 19%, contact SWD Technical Support. Water or oil present may cause poor adhesion or excessive foaming. Fill large voids with appropriate backer rods or appropriate fillers. If additional information is required, contact SWD Technical Support. 	
Steel & Other Metals	 It is the responsibility of the contractor/end user to determine proper adhesion and suitability through field testing. Blasting and/or priming is not always required. If additional information is required, contact SWD Technical Support. 	
Concrete	 If applying foam to concrete, the concrete surface should be structurally sound, clean, and curing for 28 days. Fill large voids with appropriate backer rods or appropriate fillers. Blasting and/or priming is not always required. It is the responsibility of the contractor/end user to determine proper adhesion and suitability. If additional information is required, contact SWD Technical Support. 	
Previously Applied Foam or Other Polymers	 As practical, remove previously applied foam and other polymer products. Application of product over existing materials should be performed only after adhesion/compatibility is verified by the contractor and accepted by the building owner or owner's appointed representative. 	
Wiring and Plumbing	 QUIK-SHIELD® 108YM is fully compatible with CPVC piping systems (Paschal Engineering Study for the SPFA). QUIK-SHIELD® 108YM is compatible with typical electrical wiring coverings. (NEMA Bulletin 95) 	
PROCESSING		
Preconditioning	 It is recommended to precondition material to 70°F prior to application. Material may thicken at lower temperatures which can cavitate pumps. 	
Mixing	 Use an approved drum mixer in the center bung of drum. Ensure that the mixer lid is securely attached. Use three folding blades in the following arrangement: 8" blade at the top (set four inches down from the top of the shaft), 6" blade positioned in the middle, and an 6" blade at the bottom. Mix B-Side (Resin) for 10-20 minutes depending on weather conditions with any approved mixer. Continually mix B-Side (Resin) while applying material. Mixing of A-Side (Iso) is not required. 	
Pressure Settings	 7. Product should be sprayed with a high-pressure plural-component proportioner capable of a minimum of 1000 ps dynamic pressure. 8. Static pressure is typically set between 1200-1500psi. 9. Dynamic pressure typically operates at a minimum of 1000psi. 	
Temperature Settings	10. Primary heaters and hose heaters are typically set between 115-150°F (46-66°C). Higher temperatures are utilized in winter months, lower temperatures are utilized in summer months.	
equipment, hose ler	n temperature setting is the responsibility of the end user. Equipment temperature varies and can be dependent on Igth, elevation, ambient temperature, substrate temperature, humidity, and other factors. If additional information is d, refer to QS108YM Processing Packet found on swdurethane.com and the SWD mobile app, or contact	

SWD Technical Support at 888-380-2022.

APPLICATION

- 1. Clean surfaces according to "Preparation of Substrates" section.
- 2. If priming, follow manufacturer recommendations. Ensure primer is adequately cured prior to application.
- 3. It is the contractor's responsibility to determine if ambient and substrate temperatures are conducive for spraying foam.
- When changing between products, flush an adequate amount of material through the lines/gun prior to spraying desired surface. Flush amount will be dependent on prior system used.
- 5. Before application, test material to ensure that material sprays, cures, and hardens properly.
- 6. Always hold the spray gun perpendicular to the surface being sprayed.
- 7. Inspect applied material intermittently to ensure no problems exist. If problems are detected, discontinue application and inspect all substrates, equipment, gun, and liquid material for problem source(s).
- QUIK-SHIELD[®] 108YM can fill an entire wall cavity in a single zipping motion by applying foam right up the middle of the cavity. For application tips, see SWD QUIK-SHIELD[®] 108YM Processing Packet.
- 9. QUIK-SHIELD* 108YM can be applied with Long-Range Application that enables you to spray an 8" lift from up to 15 feet away. For application tips, see SWD QUIK-SHIELD* 108YM Processing Packet.

CLEANING AND MAINTENANCE

- 1. Spray equipment must be maintained in proper operating condition. Failure to adequately maintain spray equipment may result in poor
- product performance. Refer to your equipment manufacturer's maintenance procedures for more details.
- 2. Contact SWD for long-term equipment storage recommendations.



The information herein is believed to be reliable; however, unknown risks may be present. SWD Urethane makes no warranty, expressed or implied, concerning this product's merchantability or fitness for any particular use. The product will meet the written liquid component specifications as indicated on the technical data sheet published at the time of the purchase. The entirety of SWD Urethane's responsibility is limited only to the cost of the SWD material. The foregoing constitutes SWD Urethane's sole obligation with respect to damages, whether direct, incidental or consequential, resulting from the use or performance of the product.

Safety is the responsibility of the owner, the owner's appointed representative, the contractor, and/or inspector. Become familiar with local, state, and federal regulations regarding chemical health, safety, and handling. For more information consult the product SDS, contact the SPFA (www.sprayfoam.org) or the ACC (www.spraypolyurethane.org).

SWD Urethane | 800-828-1394 | 540 South Drew St. | Mesa, AZ 85210 | swdurethane.com PUBLISH DATE: 12/2019