



QUIK-SHIELD 108

Low Density Spray Foam

QUIK-SHIELD® 108 is an open-cell spray foam insulation with a low density of 0.4lb, compared to typical 0.5lb foam. It is ideal for high-performance and air barrier insulation applications in residential (IRC) and commercial (IBC) construction. QUIK-SHIELD® 108 has superior adhesion, cohesion, and expansion that can be sprayed from long distances without compromising performance.

TYPICAL PHYSICAL PROPERTIES

Properties achieved in a lab environment at 77°F. Field conditions may cause variation in properties.

	PROCEDURE	VALUES
Air Leakage at 3.5 (L/s/m ²)	E-283	<0.02
Closed-Cell, content (%)	D-2856	<90
Core Density (nominal, lb/ft ³)	D-1622	0.4
Dimensional Stability (%)	D-2126	<15
Tensile Strength (psi)	D-1623	min 3

RELATIVE INSULATION VALUES (aged)

R-value at 1"	3.7
R-value per inch at ≥ 3.5"	3.6

IGNITION BARRIER

DC 315 (wet mils)	AC377-App X	4
Flame Seal FS 1B (wet mils)	AC377-App X	6

THERMAL BARRIER

DC 315 (wet mils)	NFPA 286	14
No-Burn Thb (wet mils)	UL1715	14

HANDLING PROPERTIES at 77°F (25°C)

	A-SIDE (ISO)	B-SIDE (RESIN)
Specific Gravity	1.23	1.06
Viscosity, cps	250±50	400±50

RECOMMENDED STORAGE AND SHELF LIFE

- Storage temperatures 50-100°F (10-38°C) See back for preconditioning of material.
- 6 month shelf life from date of manufacture (unopened containers).
- Keep container tightly sealed.
- Store out of direct sunlight, in a cool dry place, avoid freezing.

PRODUCT INFORMATION

Blowing Agent	100% Water Blown
LEED	QUIK-SHIELD® 108 has a minimum of 20.1% total renewable/recycle content, 2.2% pre-consumer recycled, 2.9% post-consumer recycled, and 15.0% rapidly renewable.
Product Color	White to off-white (UV exposure will cause discoloration. Discoloration by itself is not a sign of product damage.)
Product Packaging	55 Gallon Drum
Reentry Times	1-hour Reentry for new residential construction with natural ventilation. 12-hour Reentry for commercial/retrofit.

APPROVALS / COMPLIANCE

QUIK-SHIELD® 108 has been tested by a third party laboratory (Intertek Testings Services NA, Inc.) and evaluated by Priest and Associates Fire Consultants, LLC.

CCRR-1051	Class 1— ASTM E-84
IBC, IRC, IECC: 2009, 2012, 2015, 2018 (AC377)	GREENGUARD Gold Certified

IRC/IBC Section 316.6/2603.10 - Ignition barrier not required in unvented attics.



PREPARATION OF SUBSTRATES

Providing the proper substrate is the responsibility of the owner, the owner’s appointed representative, the contractor, and/or inspector. The following are manufacturer’s recommendations. However, other preparation techniques may be required given unique/specialized application circumstances. Contact **SWD Technical Support at 888-380-2022** for additional questions.

It is recommended to remove dust, dirt, oil, paint, and alternative polymers from all surfaces prior to applying SWD products.

See SWD specifications or SPFA guidelines for further details on substrate prep.

Wood	<ul style="list-style-type: none"> • Ensure wood is relatively dry and protect surfaces from contamination. For moisture content exceeding 19%, contact SWD Technical Support. • Water or oil present may cause poor adhesion or excessive foaming. • Fill large voids with appropriate backer rods or appropriate fillers. • If additional information is required, contact SWD Technical Support.
Steel & Other Metals	<ul style="list-style-type: none"> • It is the responsibility of the contractor/end user to determine proper adhesion and suitability through field testing. Blasting and/or priming is not always required. If additional information is required, contact SWD Technical Support.
Concrete	<ul style="list-style-type: none"> • If applying foam to concrete, the concrete surface should be structurally sound, clean, and curing for 28 days. • Fill large voids with appropriate backer rods or appropriate fillers. • Blasting and/or priming is not always required. It is the responsibility of the contractor/end user to determine proper adhesion and suitability. If additional information is required, contact SWD Technical Support.
Previously Applied Foam or Other Polymers	<ul style="list-style-type: none"> • As practical, remove previously applied foam and other polymer products. Application of product over existing materials should be performed only after adhesion/compatibility is verified by the contractor and accepted by the building owner or owner’s appointed representative.
Wiring and Plumbing	<ul style="list-style-type: none"> • QUIK-SHIELD® 108 is fully compatible with CPVC piping systems (Paschal Engineering Study for the SPFA). • QUIK-SHIELD® 108 is compatible with typical electrical wiring coverings. (NEMA Bulletin 95)

PROCESSING

Preconditioning	<ol style="list-style-type: none"> 1. It is recommended to precondition material to 90°F prior to application. Material may thicken at lower temperatures which can cavitate pumps.
Mixing	<ol style="list-style-type: none"> 2. Use an electric driven drum mixer (Fusion Fluid HD or equivalent) in the center bung of drum. Ensure that the mixer lid is securely attached. 3. Recommended folding blade arrangement: 8” blade at the top (set four inches down from the top of the shaft), 6” blade positioned in the middle, and an 6” blade at the bottom. 4. Mix B-Side (resin) on high speed for 20 minutes before application and continually mix while applying material. 5. Mixing of A-Side (iso) is not required.
Pressure Settings	<ol style="list-style-type: none"> 6. Product should be sprayed with a high-pressure plural-component proportioner capable of a minimum of 1000 psi dynamic pressure. 7. Static pressure is typically set between 1300-1600psi. 8. Dynamic pressure typically operates at a minimum of 1000psi.
Temperature Settings	<ol style="list-style-type: none"> 9. Primary heaters and hose heaters are typically set between 115-160°F (46-71°C). Higher temperatures are utilized in winter months, lower temperatures are utilized in summer months.

Proper application temperature setting is the responsibility of the end user. Equipment temperature varies and can be dependent on equipment, hose length, elevation, ambient temperature, substrate temperature, humidity, and other factors. If additional information is required, refer to QS108 Processing Packet found on swdurethane.com and the SWD mobile app, or contact **SWD Technical Support at 888-380-2022**.

APPLICATION

1. Clean surfaces according to “Preparation of Substrates” section.
2. If priming, follow manufacturer recommendations. Ensure primer is adequately cured prior to application.
3. It is the contractor’s responsibility to determine if ambient and substrate temperatures are conducive for spraying foam.
4. When changing between products, flush an adequate amount of material through the lines/gun prior to spraying desired surface. Flush amount will be dependent on prior system used.
5. Before application, test material to ensure that material sprays, cures, and hardens properly.
6. Always hold the spray gun perpendicular to the surface being sprayed.
7. Inspect applied material intermittently to ensure no problems exist. If problems are detected, discontinue application and inspect all substrates, equipment, gun, and liquid material for problem source(s).
8. QUIK-SHIELD® 108 can fill an entire wall cavity in a single zipping motion by applying foam right up the middle of the cavity. For application tips, see SWD QUIK-SHIELD® 108 Processing Packet.
9. QUIK-SHIELD® 108 can be applied with Long-Range Application that enables you to spray an 8” lift from up to 15 feet away. For application tips, see SWD QUIK-SHIELD® 108 Processing Packet.

CLEANING AND MAINTENANCE

1. Spray equipment must be maintained in proper operating condition. Failure to adequately maintain spray equipment may result in poor product performance. Refer to your equipment manufacturer’s maintenance procedures for more details.
2. Contact SWD for long-term equipment storage recommendations.



The information herein is believed to be reliable; however, unknown risks may be present. SWD Urethane makes no warranty, expressed or implied, concerning this product’s merchantability or fitness for any particular use. The product will meet the written liquid component specifications as indicated on the technical data sheet published at the time of the purchase. The entirety of SWD Urethane’s responsibility is limited only to the cost of the SWD material. The foregoing constitutes SWD Urethane’s sole obligation with respect to damages, whether direct, incidental or consequential, resulting from the use or performance of the product.

Safety is the responsibility of the owner, the owner’s appointed representative, the contractor, and/or inspector. Become familiar with local, state, and federal regulations regarding chemical health, safety, and handling. For more information consult the product SDS, contact the SPFA (www.sprayfoam.org) or the ACC (www.spraypolyurethane.org).

SWD Urethane | 800-828-1394 | 540 South Drew St. | Mesa, AZ 85210 | swdurethane.com

PUBLISH DATE: 12/2019